



onlineEXTRA

Issue #14 Dec/Jan 2007 Stamp of Approval

First-Class Classic Pattern

BOX SIDES 11/4" stock

Cut around the outside lines only, leaving the interior line intact. Do not remove pattern after cutting.

вох воттом

1/4" stock

Do not remove pattern until center hole is drilled. Use ¹⁵/₆₄" drill bit. Do not drill all the way through.

LID UNDERSIDE

1/4" stock

Cut out only the interior section, and save it for a later step. Use 1/4" drill bit.

