



Note: Make a copy of the Top and Body Templates. Spray-adhere them to the cardboard and cut to shape. Hold them against your work to check progress.