


Patio Chair


June/July 2016, Issue 71, Page 51

When paired with a plunge router equipped with a 1/2" spiral bit and 1" O.D. bushing, this mortising jig can be used to rout a single 1/2" wide x 1 1/2" long mortise for the stretcher to leg joints as a substitute for the smaller pair of Dominos used by the builder. You can also use it to rout the 1/2"-wide grooves in the back legs for the back slats.


Alternatively, you can make the T-shaped mortising jig from the Joinery Class: Loose Tenon Joinery (p.68) and make rout a pair of mortises at each joint, similar to the pair of Dominos. Set the clamping board to rout the lower mortise, and then insert a shim between clamping board and work to rout the next set.



Leg Mortising Front View



Stretcher Mortising Side View



Stretcher Mortising Front View

